


QDB30 | **Operating manual**



Introduction

Thank you for choosing a high-quality product “MADE IN GERMANY” from the brand TWAUDIÖ.

The QDB30 dolly is an accessory for the B30, VERA S30 or VERA S33 loudspeaker.

This accessory set is characterized by a subtle look, a remarkable size to weight ratio and ease of use.

If you lend your product to another party, inform that party of the safety-related operating procedures and hand over this assembly guide. If you require additional copies of this manual, you can obtain them free of charge from TWAUDIÖ or download them from www.twaudio.de

Instructions in this user manual

Strictly adhere to the instructions contained in this operating manual that are marked as follows:



This symbol in combination with the signal word “Warning” identifies a potentially hazardous situation. Failure to comply with this safety instruction can lead to serious injury or even death.



This symbol in combination with the signal word “Caution” identifies a potentially hazardous situation. Failure to comply with this safety instruction can lead to light or moderate injury.



This symbol in combination with the signal word “Note” identifies a potentially hazardous situation. Failure to comply with this safety instruction can lead to product damage.



This symbol in combination with the signal word “Tip” identifies additional information or notes that will simplify working with TWAUDIÖ products on the basis of practical experience.

Notes on the products

**Read manual
before use!**

Before using the device, carefully read the operating manual and keep it with the QDB30 dolly.

General information

Operation manual: OM-QDB30

Version 2.0 en, 02/2022

© by TWAMBO 2022; all rights reserved.

All information contained in this operating manual was correct to the best of our knowledge at the time of printing.

Quality warranties or assurance of suitability for a certain type of use based on the technical specifications, dimensions and weights are not granted by TWAMBO.

TWAMBO also shall not assume liability for any secondary damage (property damage and/or personal injury) nor for the failure to comply with this operating manual!

TWAMBO reserves the right to update this document based on recent developments.

TWAMBO GmbH
Karl-Hofer-Str. 42
14163 Berlin
Germany

Phone : + 49 (0) 71 41-48 89 89 0
Fax: + 49 (0) 71 41-48 89 89 99
E-Mail: info@twaudio.de
WWW: www.twaudio.de

Content

1. Safety Intended use	5
2. Overview	6
2.1 Components	6
3. Technical specifications	7
3.1 Data sheet	7
4. Commissioning	8
4.1 Using QDB30 dolly with B30 or VERAS30 loudspeaker	8
4.2 Using QDB30 dolly with VERAS33 loudspeaker	10
5. Transport and Storage	12
6. CE Conformity Declaration	13
7. Disposal	13

1. Safety | Intended use

Please adhere to the following safety instructions to avoid risks when using accessories.

The QDB30 dolly was developed for professional use in sound systems. The dolly may only be used by trained and qualified personnel.

Note the operating modes described in this operating manual. Other uses are not permissible.

Damage caused by improper use is not covered by TWAMBO.



Before each use, check the integrity of the QDB30 dolly and ensure that all components are in perfect condition.



The QDB30 dolly may only be used with the B30, VERAS30 or VERAS33 loudspeaker.

These operating manual describe how to use the QDB30 dolly. Any other use shall be deemed improper and may result in damage or even injury.

Modifications or alterations to individual parts of the QDB30 dolly are not permitted! Danger to life!



The QDB30 is an accessory designed both for indoor and outdoor use.



The QDB30 dolly may only be used by trained and qualified personnel. Personnel must check the QDB30 for its full suitability before each use.



When visible damage to any part of the QDB30 dolly is detected, it must be decommissioned immediately.



When moving the QDB30 dolly, ensure full load-bearing capacity and stability of the substrate.

The QDB30 dolly is specified for a load of not more than four B30 or four VERAS30 or two VERAS33 loudspeaker. This load capacity must never be exceeded!



During movement (assembly or dismantling, transport to the place of use) of the QDB30 dolly with the B30, VERAS30 or VERAS33 loudspeaker, ensure sufficient space to prevent collisions with other objects.

2. Overview

2.1 Components




Figure 2.1 - Overview

1. Dolly - Surface Warnex textured paint
2. 100mm castor with stopper (4 pieces)
3. Recesses for stacking the dollys (4 pieces)
4. Handles (4 pieces)
5. Milling for rubberfeet for safely stacking loudspeakers (4 pieces)

3. Technical specifications

3.1 Data sheet

Maximum load capacity	4x B30 or 4x VERAS30 or 2x VERAS33
Dimensions (h x w x d)	800 x 700 x 150 mm [31.5 x 27.6 x 5.9 in]
Weight	8,7 kg [19 lbs]
Surface	Warnex textured paint

4. Commissioning

4.1 Using QDB30 dolly with B30 or VERAS30 loudspeaker



Please note that two persons are always required to set up the QDB30 dolly with the B30 or VERAS30 loudspeaker!



Place a maximum of four B30 or VERAS30 loudspeakers on top of each other on the QDB30 dolly. Pay attention to the firmness of the structure in order to avoid tilting.

Attach all B30 or VERAS30 loudspeakers to the QDB30 dolly! Use a lashing strap with a ratchet.

Make sure that the lashing strap is pulled tightly and without twisting around the loudspeakers and the dolly. (see figure 4.1)



Never fasten the lashing strap over the front grill of the B30 or VERAS30 loudspeaker!



When moving the QDB30 dolly transport setup with the B30 or VERAS30 loudspeaker, note that there is a risk of tipping due to the high center of gravity.



Figure 4.1.1 - Transport setup B30 or VERAS30 loudspeaker with QDB30



The QDB30 dolly can be stacked for storage. For this purpose, recesses (see figure 2.1 - Pos.3) are provided in the dolly (see figure 2.1 - Pos.1).



When moving the stacked QDB30 dolly, note that there is a risk of tipping on each individual QDB30 dolly.




Figure 4.1.2 - Stacking the QDB30 dolly

4.2 Using QDB30 dolly with VERA S33 loudspeaker



Please note that two persons are always required to set up the QDB30 dolly with the VERAS33 loudspeaker!



Place a maximum of two VERA S33 loudspeakers on top of each other on the QDB30 dolly. Pay attention to the firmness of the structure in order to avoid tilting.

Attach the two VERA S33 loudspeakers to the QDB30 dolly with the Cover2S33 protective cover. (not shown in figure 4.2)



When moving the QDB30 dolly transport setup with the VERAS33 loudspeaker, note that there is a risk of tipping due to the high center of gravity.




Figure 4.2.1 - Transport setup VERA S33 loudspeaker with QDB30



The QDB30 dolly can be stacked for storage. For this purpose, recesses (see figure 2.1 - Pos.3) are provided in the dolly (see figure 2.1 - Pos.1).



When moving the stacked QDB30 dolly, note that there is a risk of tipping on each individual QDB30 dolly.




Figure 4.2.2 - Stacking the QDB30 dolly

5. Transport and Storage



NOTE

Ensure that the surface of the dolly is not damaged during transport and storage. Moisture can penetrate through exposed wood surfaces and cause the wood to swell.

This is why the product should be transported in a safe, careful, dry and largely dust-free manner.

The following transport and storage accessories are available from TW AUDIO:

- Cover2S33 (Protective cover)
- Lashing strap

The original packaging is unsuitable as permanent storage and transport packaging.

6. CE Conformity Declaration

Copy and translation of the original CE Conformity Declaration:



We hereby declare that the below-referenced components by virtue of their design and construction, and in the configuration placed on the market by us, satisfy the safety and health requirements of the applicable EC directives. This declaration becomes invalid in case of modifications that have not been approved by us.

This declaration applies to the following components

- QDB30

as well as all model variants based on these, provided that they correspond to the original factory models and have not been technically modified in any way.

Applicable directives:

- 2001/95/EG

Applicable national standards and technical specifications:

- DIN EN ISO 12 100
- DGUV Vorschrift 17 und 18

Berlin, Germany, January 1st, 2021


Bernhard Wüstner

7. Disposal

If you have any question regarding the disposal of used devices, please contact us under the following telephone number:

+49 (0) 71 41 - 48 89 89 0

In countries outside of the European Union, comply with local regulations.

TWAMBO GmbH
Karl-Hofer-Str. 42
14163 Berlin
Germany

Phone: + 49 (0) 71 41-48 89 89 0
Fax: + 49 (0) 71 41-48 89 89 99
E-Mail: info@twaudio.de
WWW: www.twaudio.de